


## Unlocking Instructions:

1. Swing screwdriver tips toward you.
2. Pull pliers handles outward to open jaws and remove from "dock."




**SWISS+TECH®**  
*First in Key Ring Products™*

Visit Our Website at [www.swisstechtools.com](http://www.swisstechtools.com)

## Micro-Pro™ XL 11-in-1 Key Ring Tool Set


1. #2 Flat Screwdriver
2. #2 Phillips Screwdriver
3. #1 Flat Screwdriver
4. #1 Phillips Screwdriver
5. Wire Stripper
6. Wire Cutter
7. Pliers
8. Sheet Shear
9. 1/4" Rule
10. Flashlight
11. Key Ring



### Micro-Pro™ XL Additional Features

## Micro-Pro™ 9-in-1 Key Ring Tool Set

1. #2 Flat Screwdriver
2. #2 Phillips Screwdriver
3. Wire Stripper
4. Wire Cutter
5. Pliers
6. Sheet Shear
7. 1/4" Rule
8. Flashlight
9. Key Ring



Patent #5,491,856  
Patents Pending

### Positions for tool use:



**SWISS+TECH®**  
*First in Key Ring Products™*

### Limited LIFETIME Warranty

Your SWISS+TECH® brand tool is warranted for the life of the user against any defects in material or workmanship. All Docking Stations are warranted for one year against any defect in material or workmanship.

Abuse, battery expiration and surface coatings, which are subject to normal wear and environmental conditions, are excluded from the warranty.

Simply return your SWISS+TECH® brand product postpaid and insured to:

SWISS+TECH Products  
701 Beta Drive, Unit 5  
Mayfield Village, Ohio 44143

Made in China

## Micro-Flash Drive Tool Dock



Easy to plug and unplug!

- + High Speed USB 2.0 Compatible
- + No drivers required (except Windows 98)
- + No external power adaptor needed

### System Requirements

Please visit our website for complete information. The basic features of USB flash disk are available in Microsoft Windows, MAC OS and Linux operating systems.

Additional application software available at [www.swisstechtools.com](http://www.swisstechtools.com) requires the following system environment:

Computer IBM PC/AT compatible, Power Macintosh, PowerBook, iMAC or iBook.

Operating System Windows 98, Windows ME, Windows 2000, Windows XP, Linux 2.4 or above, Mac OS 9.0 or above.

### Windows XP Users

If you have more than one hard drive, you may experience a drive naming conflict. If so, here's how to fix it:

1. Go to the "Control Panel"
2. Double-click "Administrative Tools"
3. Double-click "Computer Management"
4. Click on "Disk Management"
5. In the right-hand panel, drives will be listed, right-click on the drive you want to change, then select "Change Drive Letters and Paths"
6. Select a new drive letter, click "OK"
7. Close all dialogs

### Windows 98 Users

Windows 98 does not have built-in USB support. Please visit our website, [www.swisstechtools.com](http://www.swisstechtools.com) to download the necessary drivers.


### WARNING:

Do not disassemble or change any part of this product. Do not contact this product with water or other liquid. If that happens, immediately disconnect this product from the computer to prevent a possible short-circuit or fire.

Do not plug-in or plug-out this product with wet hands. This could cause a short-circuit. Keep this product from fire or high temperature places.

Do not expose this product to electromagnetic sources, which could cause product damage and/or data loss.

## USB Flash Drive



### Component Descriptions

**LED Indicator:** Indicates status of disk. LED blinks while disk is being accessed.

**Write Protect Switch:** If "ON", the disk is write-protected; files on disk are readable, but no new files may be written.

**USB Connector:** Connects to USB socket on computer.

### WARNING:

Do not un-plug the disk if the LED is fast blinking, indicating disk is in use. This may cause data or file corruption.